

SeeSaw Installation

Wiring Connections

Setting up the SeeSaw is very straightforward. All it needs is to be plugged into power, and then the external light needs to be plugged in to the SeeSaw.

The SeeSaw has two jacks – a jack for power input, and a jack to connect to the external light.



Optionally, an extension for the power cable is provided if the nearest power outlet is far away from where the SeeSaw will be installed.



Installation on Equipment

The SeeSaw needs to be placed on or very close to the motor of the equipment that it is being set up on to detect when the motor is spinning. The SeeSaw can be attached with a strap, rubber band, or velcro strips. The photos below show one of the recommended methods of installation:



When the motor is not spinning, the light on the SeeSaw will be green.

When the motor is spinning, even after the equipment has been turned off, the SeeSaw will be red.

The external light should be placed on the equipment in a place where it is highly visible but not intrusive or obstructive to using the machine. It can be attached with the included magnet, a rubber band, strap, or velcro strips.